



DISINFECTANTS

LUFRA ULTRACHLOR

CHLORINE DISINFECTION TABLETS

- ACTIVE AGAINST A RANGE OF BACTERIA, VIRUSES, YEASTS AND SPORES (C. DIFFICILE)
- FAST TO DISSOLVE
- LONG SHELF LIFE, PERFECT FOR STORAGE WHEN NEEDED

PRODUCT DESCRIPTION

LUFRA ULTRACHLOR tablets are designed to produce 1000 ppm (parts per million) solutions of chlorine, which can be used to sanitise high risk areas. Ideal to disinfect tables, chairs, mobility equipment, bed frames, toilets, sinks etc.

Use if needed as a back-up product to complement 'Lufra Ultrafresh Protect' in the case of outbreaks or extended microbial control requirements.

EFFICACY

Provided in an easy to use tablet form, which is readily dissolvable in water. LUFRA ULTRACHLOR has been tested against a range of standards, at a dilution as shown below by an independent laboratory.

STANDARD	DILUTION RATE	CONDITIONS	CONTACT TIME	PASSED
<u>Bactericidal</u> EN 1276	1 tablet per Litre	Clean	5 Minutes	≥5 log reduction
<u>Yeasticidal</u> EN 1650	1 tablet per Litre	Clean	5 Minutes	≥4 log reduction
<u>Viricidal</u> EN 14476 (Norovirus)	1 tablet per Litre	Clean	5 Minutes	≥4 log reduction
EN 14476 (Feline coronavirus)	1 tablet per Litre	Clean	5 Minutes	≥4 log reduction
<u>Sporicidal</u> EN 13704 (Bacillus subtilis)	1 tablet per Litre	Clean	15 Minutes	≥3 log reduction
EN 17126 (Clostridium difficile)	1 tablet per Litre	Clean	15 Minutes	≥4 log reduction

INSTRUCTIONS FOR USE

Clean first with detergent, apply the chlorine solution to the surface to be disinfected and wait for the required contact time. Wipe away if required. When disinfecting, use enough liquid so that the surface remains wet during the required contact time. Always use a fresh solution every 24 hours. May bleach certain materials, always test on a small area first.

Use biocides safely. Always read the label and product information before use.

DILUTION RATE

Sanitising (Bacteria, Yeast, Viruses, Spores)	1 tablet in 1 Litre of water
---	------------------------------

ADDITIONAL INFORMATION

Product code:	275
pH Level in water:	5-6

MAY BLEACH CERTAIN MATERIALS, ALWAYS TEST ON A SMALL AREA FIRST

STORAGE

Use above 5°C. Store in a cool, dry, well-ventilated place, ideally below 25°C with container lid tightly closed.

PACKAGING

6 x Tubs	200 tablets (approx.) per tub
----------	-------------------------------

NON WARRANTY

This information is based on our current knowledge and is intended to describe the product for the purposes of health, safety and environmental requirements only. It should not therefore be construed as guaranteeing any specific property of the product.